

K50i Series

Technical Manual



K50F + K51S



K50F




K50P

03 April 2008

Version 1.01

M. Hume



RAYTEL SECURITY SYSTEMS

Southern Office:

Raytel House
Brook Road
Rayleigh
Essex,
SS6 7XH

Tel: (01268) 749311
Fax: (01268) 749315

Northern Office:

20-23 Woodside Place,
Glasgow,
Strathclyde,
G3 7QF.

Tel: (0141) 5821275

CONTENTS

SYSTEM OVERVIEW

Key Features and Connectors	3
Box Contents & Installation	4
Specification.....	5

SYSTEM DIAGRAMS

Earth Connection	6
Fail Safe Lock Wiring and Programming	7
Fail Secure Lock Wiring and Programming	8
Fail Safe Lock Wiring and Programming with Keypad In/Out.....	9
Fail Secure Lock Wiring and Programming with Keypad In/Out	10
Wiring and Programming with Door Entry Systems	11
Single Door Proximity with Fail Safe Lock Wiring and Programming	12
Single Door Proximity with Fail Secure Lock Wiring and Programming	13
Doorbell Function Wiring and Programming	14
Alarm, Tamper and Door Contact Wiring and Programming	15
Lift Control Wiring and Programming.....	16
Up to 254 Keypads Direct to PC.....	17
Up to 254x16 Keypads using 716E 16 Door Controller.....	18
Up to 254 Keypads Direct to PC with RS-485 Repeater	19

BASIC PROGRAMMING

Entering/Exiting Programming.....	20
Factory Reset, Changing Master Code and Lock Time	20
Adding User Codes, Enabling RTE and Setting Latch Mode.....	21
Anti-Passback.....	22

ADVANCED PROGRAMMING

Adding/Deleting Tokens	23
Doorbell Function.....	24
Alarm Functions.....	25
Lift Control.....	26
Setting AR-401RO16B DIP Switches	27
Auto-Open Zone Programming	28
Programming Charts.....	29
Resetting Master Code	30

NETWORKING

Connecting Directly to a PC.....	31
Networking Under an AR-716E.....	34

PROGRAMMING CHART	35
--------------------------------	----

TABLE OF USERS	36
-----------------------------	----

SYSTEM OVERVIEW


Key Features

The K50P is a versatile Keypad capable of many functions and several different mounting options.

Key Features:

- Upto 1024 different 4 digit user codes
- 2 internal open time zones
- Tamper Switch
- 32 floor lift control
- Door Monitoring
- Code in/Code out (with additional Wiegand Keypad)
- Optional Anti-pass back function with Code In/Out
- Egress Button
- Network capability up to 254 x 16 doors each with Keypad In/Out
- Duress Code
- Optional Lock Outputs - Timed 0.1 to 600 seconds, Latched On/Latched Off
- Universal Serial Port for LED Display, Printer, Lift Control etc.
- Alarm function for Tamper, Forced Entry, Duress and Door Open
- Will run as a Standalone Controller during Host Controller failure
- Proximity Card flash edit mode
- Buffer for up to 1200 Transactions
- Auto-Relock Function
- Real Time Clock

Connectors



P1 Table 1: Connector P1 colour coding.

Wire Application	Wire	Colour	Description
Door Relay	1	Blue/White	(N.O.) DC24V 1A
	2	Purple/White	(N.C.) DC 24V 1A
	3	White	(COM) DC24V 1A
Door Sensor	4	Orange	Negative Trigger Input
Exit Switch	5	Purple	Negative Trigger Input
Alarm Output	6	Grey	Transistor Output (Open Collector Active Low)
Power	7	Thick Red	DC Power 12V
	8	Thick Black	DC Power 0V

P2 Table 2: Connector P2 colour coding.

Wire Application	Wire	Colour	Description
Host Connection	1	Thick Green	RS-485 (B-)
	2	Thick Blue	RS-485 (A+)
Wiegand	3	Thin Blue	Wiegand DAT:1 Input
	4	Thin Green	Wiegand DAT:0 Input
Sounder	5	Pink	Sounder Output 5V/100mA, Low
LED	6	Brown	Green LED Output 5V/20mA, Max
	7	Yellow	Red LED Output 5V/20mA, Max

P3 Table 3: Tamper Switch Connector P3 colour coding.

Wire Application	Wire	Colour	Description
Tamper Switch	1	Red	Normally Closed
	2	Orange	Common
	3	Yellow	Normally Open


Contact Rating: 1A 125VAC/24VDC

SYSTEM OVERVIEW


Box Contents and Installation

K50P

A. Keypad and Cover




B. Manual




C. Leads



D. Screws and Torx Wrench




E. Gasket




- A. Connect wires as required, see previous page.
- B. Plug connectors into Keypad.
- C. Screw Keypad to the wall.
- D. Fit cover onto Keypad.
- E. Apply power, Red LED will flash and sounder will beep.
- F. Commence programming as required.

K50F

A. Keypad





B. Manual



C. Leads




D. Screws and Torx Wrench




- A. Fit backbox FB146 (supplied separately) into the wall.
- B. Connect wires as required, see previous page.
- C. Plug connectors into Keypad.
- D. Screw Keypad to the backbox.
- E. Apply power, Red LED will flash and sounder will beep.
- F. Commence programming as required.

K50CS (K50F + K51S)

A. Keypad and Shroud





B. Manual



C. Leads



D. Screws and Torx Wrench



- A. Screw K51S to the wall.
- B. Connect wires as required, see previous page.
- C. Plug connectors into Keypad.
- D. Screw Keypad to the K51S.
- E. Apply power, Red LED will flash and sounder will beep.
- F. Commence programming as required.

WARNING

The communication and power cables should not be housed in the same electrical conduit. They should always be installed in separate conduit.


SYSTEM OVERVIEW

K50i Specification				
Mode No.		M4	M6	M8
User Capacity		1,024	65,536	1,024
Event Log		1,200	N/A	1,200
Access Mode		5-Digit User Address+ 4-Digit Individual Password	4-Digit Public Password	4-Digit Individual Password
Support		Stand-Alone / Networking		
Voltage		9-24 VDC 9-18 VAC		
Power Requirement		<3W		
Communication Interface		RS-485		
Baud Rate		9600 bps (N, 8, 1)		
Operating Temperature		-20°C ~ +75°C		
DI Input		Egress Button Door Sensor		
DO Output		1 Door Relay Output		
Transistor Output		Duress/Alarm/Arming LED		
Door Relay Time		0, 0.1~600 sec.		
Alarm Relay Time		0, 1~600 sec.		
Tamper Resist. Switch		Limit Switch (Form C)		
Anti-Passback		Yes		
Serial Out		TTL (4800 bps, N, 8, 1)		
IP Rating		IP65		
Real Time Clock		Yes		
Indicator		1 Bi-Colour LED 1 Piezo Sounder		
Colour	PBT Housing	Gray ABS Plastic		
	Metal Box	Brushed Stainless Steel		
Dimensions (mm)	PBT only	113.75(L)x65.20(W)x28.20(H)		
	Metal Box	150(L)x92(W)x49.28(H)		
Housing Material		PBT Keypad Housing Metal box: 316 Stainless Steel		

IMPORTANT NOTE.


FOR ILLUMINATED KEYPADS

The green earth lead on this unit **MUST** be connected to a suitable earth point to avoid the possibility of damage from electro-static discharge.




Please note that all drawings and diagrams supplied for bespoke applications for RSS products are given as a free service to assist customers and no liability for errors and omissions can be accepted by RSS. Customers remain entirely responsible for the quality and correctness of all installation work.


ISS	DESCRIPTION	DATE	TITLE		DRAWN	CHECKED	APPROVED	DATE
1	INITIAL	15 - 04 - 10	THE RAYTEL GROUP LTD		MH			15 - 04 - 10
			K50i Series Earth Lead					
			DRAWING No.				RSS 2000/520	



Please note that all drawings and diagrams supplied for bespoke applications for RSS products are given as a free service to assist customers and no liability for errors and omissions can be accepted by RSS. Customers remain entirely responsible for the quality and correctness of all installation work.				TITLE		DATE	
ISS	DESCRIPTION	INITIAL	DATE	DRAWN	CHECKED	APPROVED	DATE
1			11 - 02 - 08	MH	JJT	JJT	11 - 02 - 08
				DRAWING No. RSS2000/79			




Please note that all drawings and diagrams supplied for bespoke applications for RSS products are given as a free service to assist customers and no liability for errors and omissions can be accepted by RSS. Customers remain entirely responsible for the quality and correctness of all installation work.				TITLE		DATE	
ISS	DESCRIPTION	INITIAL	DATE	DRAWN	CHECKED	APPROVED	DATE
	1		11 - 02 - 08	MH	JT	JT	11 - 02 - 08
THE RAYTEL GROUP LTD				DRAWING No. RSS2000/80			




IMPORTANT.
A Diode **MUST** Be Fitted
To The Lock As Shown

Please note that all drawings and diagrams supplied for bespoke applications for RSSD products are given as a free service to assist customers and no liability for errors and omissions can be accepted by RSSD. Customers remain entirely responsible for the quality and correctness of all installation work.			TITLE		DATE	
RSS	DESCRIPTION	INITIAL	THE RAYTEL GROUP LTD		11 - 02 - 08	
1			K50i connection diagram with keypad in/out and fail safe lock			
			DRAWING No. RSS2000/81			
			DRAWN MH	CHECKED JUT	APPROVED JUT	DATE 11 - 02 - 08




Please note that all drawings and diagrams supplied for bespoke applications for RSS products are given as a free service to assist customers and no liability for errors and omissions can be accepted by RSS. Customers remain entirely responsible for the quality and correctness of all installation work.




Please note that all drawings and diagrams supplied for bespoke applications for RSS products are given as a free service to assist customers and no liability for errors and omissions can be accepted by RSS. Customers remain entirely responsible for the quality and correctness of all installation work.


ISS	DESCRIPTION	DATE	THE RAYTEL GROUP LTD		TITLE	K50i basic connection diagram with fail secure lock and prox reader		
1	INITIAL	11 - 02 - 08						
2	Add AR-737HB-RAY Reader	25 - 07 - 08						
						DRAWING No. RSS2000/85		
						APPROVED JUT		
						CHECKED JUT		
						DATE 11 - 02 - 08		



Please note that all drawings and diagrams supplied for bespoke applications for RSS products are given as a free service to assist customers and no liability for errors and omissions can be accepted by RSS. Customers remain entirely responsible for the quality and correctness of all installation work.		TITLE		DATE	
ISS	DESCRIPTION	INITIAL	DATE	APPROVED	DATE
1			11 - 02 - 08	JT	11 - 02 - 08
THE RAYTEL GROUP LTD			K50i connection diagram for doorbell function		
DRAWING No.			RSS2000/103		




Please note that all drawings and diagrams supplied for bespoke applications for RSS products are given as a free service to assist customers and no liability for errors and omissions can be accepted by RSS. Customers remain entirely responsible for the quality and correctness of all installation work.			TITLE			K50i connection diagram for alarm, tamper and door contacts			DRAWING No. RSS2000/86			DATE 11 - 02 - 08		
ISS	DESCRIPTION	INITIAL	THE RAYTEL GROUP LTD											
1														




Please note that all drawings and diagrams supplied for bespoke applications for RSS products are given as a free service to assist customers and no liability for errors and omissions can be accepted by RSS. Customers remain entirely responsible for the quality and correctness of all installation work.

ISS	DESCRIPTION	DATE	DRAWN	CHECKED	APPROVED	DATE
1	INITIAL	11 - 02 - 08	MH			11 - 02 - 08
THE RAYTEL GROUP LTD						
K50i Connection diagram for lift control						
DRAWING No. RSS2000/90						



ISS		DESCRIPTION		DATE		TITLE		Please note that all drawings and diagrams supplied for bespoke applications for RSS products are given as a free service to assist customers and no liability for errors and omissions can be accepted by RSS. Customers remain entirely responsible for the quality and correctness of all installation work.			
1		INITIAL		11 - 02 - 08		THE RAYTEL GROUP LTD		K50i connection diagram for up to 254 keypads direct to PC			
								DRAWING No. RSS2000/87			

ADDITIONAL CONNECTION DIAGRAM



Please note that all drawings and diagrams supplied for bespoke applications for RSS products are given as a free service to assist customers and no liability for errors and omissions can be accepted by RSS. Customers remain entirely responsible for the quality and correctness of all installation work.		TITLE		DATE	
RSS	DESCRIPTION	DATE	DRAWN	CHECKED	APPROVED
1	INITIAL	11 - 02 - 08	MH	JJT	JJT
THE RAYTEL GROUP LTD			DRAWING No. RSS2000/88		
K50i connection diagram for up to 254 keypads direct to PC with 485 repeater					

BASIC PROGRAMMING

Entering and Exiting Programming Mode

To Enter Programming Mode → (★ 123456 # default code)

To Exit Programming Mode →

Factory Reset, Changing Master Code & Lock Time

1. Restoring Factory Settings

To Reset Keypad → → → →
→ → → →

2. Changing the Master Code

To Change Master Code →

4. Changing the Lock Time

To Change Lock Time →

3. Changing the Control Mode

To Change Control Mode →

Enter 4 For Control Mode 4

Enter 6 For Control Mode 6

Enter 8 For Control Mode 8

See below.

Mode Application	M4	M6	M8
System	Stand-Alone Networking	Stand-Alone	Stand-Alone Networking
Code Capacity	1024	1	1024
Access Mode	9-Digit Individual Code	4-Digit Common Code	4-Digit Individual Code
Event Capacity	1200	N/A	1200
Holiday Function	Yes	No	Yes
Duress	Yes	No	Yes
Time Zone	11	N/A	11
Lift Control	32	N/A	32
Anti-Passback	Yes	N/A	Yes

NOTICE

Most applications require the Keypad to be set up in Mode 8.

BASIC PROGRAMMING

Adding User Codes, Enabling RTE and Latch Mode

1. Adding Individual User Codes

To Add Individual User Codes in Mode 8 → 12 ★ User Address ★ 4-Digit Code #

2. Adding a Common Code

To Add a Common Code in Modes 4 and 6 → 15 ★ 4-Digit Common Code #

3. Setting the Lock to Latch Mode

To Set Latch Mode → 02 ★ 000 #

4. Enabling Exit Function

To Enable Exit Function → 20 ★ 016 #

5. Deleting Individual User Codes

To Delete Individual User Codes → 10 ★ Start Address ★ End Address #

NOTICE

Refer to Chart A 20★DDD# on page 29 for the values needed for programming the Exit Function.

BASIC PROGRAMMING

Anti-Passback

1. Enabling Anti-Passback (Optional)

To Enable Anti-Passback → 20*128#

2. Enable User For Anti-Passback (Optional)

To Enable Users for Anti-Passback

→ 26 ★ Start Address ★ End Address ★ 0 = Enable or 1 = Disable #

NOTICE

*Refer to Chart A 20*DDD# on page 29 for the values needed for programming Anti-Passback.*

ADVANCED PROGRAMMING

Adding/Deleting Tokens

1. Adding a Single/Multiple Non Sequential Random Token

To Add Single/Non Sequential Token → 19 ★ User Address ★ Token Quantity #

Present Token to Reader.

When adding multiple tokens the User Address will automatically increase with each Token.

2. Adding Multiple Sequential Tokens

To Add Multiple Sequential Tokens → 19 ★ User Address ★ Token Quantity #

Present Lowest Numbered Token to Reader.

3. Deleting Tokens

To Delete Tokens → 10 ★ Start User Address ★ End User Address #

3. Suspending Tokens

To Suspend Tokens → 10 ★ Start User Address 9 End User Address #

Example

Deleting a Single Token

Enter Programming Mode → ★ Master Code # → 10 ★ 00001 9 00001 # → ★ #

(00001 = Start User Address, 00001 = End User Address)

Token 00001 has been Deleted.

Suspending Multiple Tokens

Enter Programming Mode → ★ Master Code # → 10 ★ 00001 ★ 00010 # → ★ #

(00001 = Start User Address, 00010 = End User Address)

Tokens 00001 - 00010 have been Suspended.

NOTICE

Refer to Table of Users for User details before deleting Tokens.

ADVANCED PROGRAMMING

Doorbell Function

2. Enabling Doorbell Function

To Enable Doorbell Function → 24 ★ 128 #

24★DDD#

FUNCTION	OPTION		VALUE	APPLICATION
	0	1		
Auto-Open Door Without Presenting Card at Auto Open Zone	Disable †	Enable	001	Networking/ Stand-Alone
Alarm Output/Lift Control	Alarm Output †	Lift Control	002	Networking/ Stand-Alone
Stop Alarm By...	None †	Push Button/ Door Closed	064	Networking/ Stand-Alone
Door Bell	Disable †	Enabled	128	Networking/ Stand-Alone

† = Default Setting

Example

To enable Auto-Open Door , Alarm Output and Doorbell, add the values of these functions together:-

Auto-Open Door = 001
Doorbell = 128
Total = 129

Enter Programming Mode → ★ 123456 # → 24 ★ 129 # → ★ #

(129 is the sum of the required values for programming)

NOTICE

Refer to the charts on page 29 for full Programming Values.

WARNING

Enabling the Doorbell function will disable the Door Monitor Alarm function.

ADVANCED PROGRAMMING

Alarm Functions

2. Enabling Alarm Output Function

To Enable Alarm Output → 24 ★ 000 #

3. Enabling Stop Alarm By...

To Enable Stop Alarm By... → 24 ★ 064 #

4. Enabling Auto Relock

To Enable Auto Relock → 20 ★ 002 #

5. Enabling Force Open Alarm Output

To Enable Force Open Alarm Output → 28 ★ 128 #

6. Changing Alarm Relay Time

To Change Alarm Relay Time → 03 ★ 3-Digit Alarm Relay Time in Seconds #

7. Changing Alarm Delay Time

To Change Alarm Delay Time → 06 ★ 3-Digit Alarm Delay Time in Seconds #

NOTICE

Refer to the charts on page 29 for full Programming Values.

ADVANCED PROGRAMMING

Enabling Lift Control & Setting Relay Time

1. Enabling Lift Control Function

To Enable Lift Control Function → 24 ★ 002 #

2. Setting Relay Time

To Set Relay Time → 23 ★ Node ID of Lift Controller ★ 3-Digit Relay Time in Seconds #

Optional Floor Access Programming

3a. Single Floor Programming

To Program Single Floors → 27 ★ User Address ★ Floor Number 01 - 32 #

3b. Multiple Floor Programming

To Program Multiple Floors → 21 ★ User Address ★ Lift Set 1 - 4 ★ 7-Digit Floor Number #

Examples

4. Single Floor Programming

Enter Programming Mode → ★ MASTER CODE # → 27 ★ 00001 ★ 07 # → ★ #

(00001 = User Address, 07 = Floor Number 01 - 32)

User 00001 is programmed for access to floor 07

5. Multiple Floor Programming

Enter Programming Mode → ★ MASTER CODE # → 21 ★ 00001 ★ 3 ★ 00001111 #

(00001 = User Address, 3 = Floors 25 - 32 & 00001111 = Floor Numbers 28 - 25) → ★ #

00000001 = Floors 1, 9, 17 & 25
 00000010 = Floors 2, 10, 18 & 26
 00000100 = Floors 3, 11, 19 & 27
 00001000 = Floors 4, 12, 20 & 28
 00010000 = Floors 5, 13, 21 & 29
 00100000 = Floors 6, 14, 22 & 30
 01000000 = Floors 7, 15, 23 & 31
 10000000 = Floors 8, 16, 24 & 32

Set	Floor/Stop							
	F	F	F	F	F	F	F	F
0	8	7	6	5	4	3	2	1
1	16	15	14	13	12	11	10	9
2	24	23	22	21	20	19	18	17
3	32	31	30	29	28	27	26	25

NOTICE


When Programming Floors, follow the parameters for either Single Floor or Multiple Floors, NOT both.

Refer to Chart 24 ★ DDD # on page 29 for all of the values needed for programming and ensure ALL Users have been added.


ADVANCED PROGRAMMING

Setting AR401-RO16B DIP Switches

Default DIP Switch settings on the AR-401RO16B are as follows:-




Floor Access is determined by the Node ID, which is set by Dip Switches 1 to 4. The Node ID of the AR-401RO16 must be set up to one of the following numbers.



- ID 1 = Floors 1 - 16
- ID 2 = Floors 17 - 32
- ID 3 = Generally Not Used
- ID 4 = Floors 33 - 48
- ID 5 = Floors 49 - 64

The Baud Rate is the communication speed between the AR-401RO16 and the associated access controller. The Baud Rate must be set to 4800 (Switches 5 on and 6 off).

All Relay outputs can be set so all Relays are Normally Open or Normally Closed via the DIP Switch. DIP Switch 8 sets the state of all the Relays, in addition individual Relays can be set to Normally Open or Normally Closed separately via the Jumpers on each relay circuit.



The default setting is with the Switch set to N.C. and the Jumpers set to NC. In this mode the Relays are normally open and normally closed when operated.

Alternative settings are:-

With the Switch set to N.C. and the Jumpers set to NO, the Relays are closed going open.

With the Switch set to N.O. and the Jumpers set to NC, the Relays are closed going open.

With the Switch set to N.O. and the Jumpers set to NO, the Relays are open going closed.

ADVANCED PROGRAMMING

Auto-Open Zone Programming

1. Enable/Disable Auto-Open Zone

To Enable/Disable Auto-Open Zone → **20 ★ 004 #**

(Refer to Chart 20*DDD# below for additional function values)

2. Enable/Disable Auto-Open Zone without Presenting a Token

To Enable/Disable Auto-Open Zone without Presenting a Token → **24 ★ 001 #**

(Refer to Chart 24*DDD# on page 23 for additional function values)

3. Open Time Setup

To Set Auto-Open Zones → **08 ★ Auto-Open Zone ★ Start Time & End Time ★ Days #**

When Setting Days, 1 = Enable 0 = Disable)

20 ★ DDD

FUNCTION	OPTION		VALUE	APPLICATION
	0	1		
Time Attendance	Yes †	No	001	Networking
Auto Relock	Disable †	Enable	002	Networking/ Stand-Alone
Auto Open	Disable †	Enable	004	Networking/ Stand-Alone
Exit by Push Button	Disable †	Enable	016	Networking/ Stand-Alone
Master Reader of Network	Slave †	Master	032	Networking
Access/Exit Reader	Exit †	Access	064	Networking
Anti-Passback	Disable †	Enable	128	Networking

Example

1. Enable/Disable Auto-Open Zone without Presenting a Token

Enter Programming Mode → **★ MASTER CODE #** → **24 ★ 001 #** →

08 ★ 1 ★ 08301000 ★ 0111110 # → **★ #**

24 ★ 001 # = Auto-Open Zone enabled, refer to page 23 for details.

08 ★... 1 = Second Auto-Open Zone enabled
08301000 = Auto-Open Time set from 0830 to 1000
0111110 = Mon - Fri set .

LIFT CONTROL AND ALARM PROGRAMMING CHARTS

20 ★ DDD #				
FUNCTION	OPTION		VALUE	APPLICATION
	0	1		
Time Attendance	Yes †	No	001	Networking
Auto Relock	Disable †	Enable	002	Networking/ Stand-Alone
Auto Open	Disable †	Enable	004	Networking/ Stand-Alone
Exit by Push Button	Disable †	Enable	016	Networking/ Stand-Alone
Master Reader of Network	Slave †	Master	032	Networking
Access/Exit Reader	Exit †	Access	064	Networking
Anti-Passback	Disable †	Enable	128	Networking
† = Default Setting				
24 ★ DDD #				
FUNCTION	OPTION		VALUE	APPLICATION
	0	1		
Auto-Open Door Without Presenting Card at Auto Open Zone	Disable †	Enable	001	Networking/ Stand-Alone
Alarm Output/Lift Control	Alarm Output †	Lift Control	002	Networking/ Stand-Alone
Stop Alarm By...	None †	Push Button/ Door Closed	064	Networking/ Stand-Alone
Door Bell	Disable †	Enable	128	Networking/ Stand-Alone
† = Default Setting				
28 ★ DDD #				
FUNCTION	OPTION		VALUE	APPLICATION
	0	1		
Two Door Opening	Disable †	Enable	064	Networking/ Stand-Alone
Force Open Alarm Output	Disable †	Enable	128	Networking/ Stand-Alone
† = Default Setting				

ADVANCED PROGRAMMING


Resetting Master Code

The Master Code can only be reset by connecting to a PC or laptop with the Soyal Access Control Software installed as follows:-

Connect the keypad to the PC using an AR-701CM RS-232/RS-485 Converter or an AR-321CM USB/RS-485 Converter.



Open ISP Tools  the following window will open.



- 1 Select "AR721H/W,757,RAY737,401DIO,725U,721_SIM(EM/MIF)"
- 2 Set the correct Node Number (Default 1)
- 3 Select the correct COM Port
- 4 Click "Reset Master Code (72xH)" button

The Master Code is now reset to the default setting of **★ 123456 #**

NOTICE

For full software installation instructions and details of COM port number, please refer to the AR-321 Driver, Soyal Device Tools, 701 Server & 701 Client Installation and Setup Manual, which can be found in the downloads section of our website or by following the link below.

<http://www.raytelsecurity.co.uk/downloads/Soyal%20Driver%20and%20Software%20Installation%20and%20Setup%20Manual.pdf>

NETWORKING

Connecting Directly to a PC

1. Setting Node ID

To Set Node ID → 00 * Keypad Node ID * Virtual 716E Node ID * Door Number #


Example

Enter Programming Mode → * MASTER CODE # → 00 * 001 * 001 * 001 # → * #


Setting up the Keypad with 701 Server Software is performed as follows:-

Right click on “My Computer” on the desktop, or click on “Start” then right click on “My Computer”

Click on “Properties”




Click on “Hardware”




Click on “Device Manager”



Click on “+” next to “Ports (COM & LPT)”



“Prolific USB-to-Serial Comm Port (COM?)”
Will show the COM Port the USB converter
is connected to.




Continued Over

NETWORKING


Connecting Directly to a PC Continued

Right click on 701 Server icon on the toolbar and click Run




Login to 701 Server, default password and user name are both supervisor.

Click on button 1, Com




Select the following (see below):-

- 1 Select COM Port
- 2 Tick Polling Message From Controller
- 3 Set Polling Interval to 200ms
- 4 Click Yes



Click on button 2, LAN



Continued Over

NETWORKING

Connecting Directly to a PC Continued

Select the following (see below):-

- 1 Tick Keypad Node ID
- 2 Select 721E
- 3 Set LAN BASE to AR-7xx/8xxE
- 4 Set Node Range to 000-007
- 5 Click Yes

Node Number	Node Name	IP Address	Port
000	727/747H V3	0 . 0 . 0 . 0	0
☒ 001	721E	0 . 0 . 0 . 0	0
☐ 002	716Ev5	0 . 0 . 0 . 0	0
☐ 003	881E/82xEv5/725Ev2/883E	0 . 0 . 0 . 0	0
☐ 004	725H/321H/327H 3K	0 . 0 . 0 . 0	0
☐ 005	821EV	0 . 0 . 0 . 0	0
☐ 006	725E	0 . 0 . 0 . 0	0
☐ 007	821EF v9	0 . 0 . 0 . 0	0
	AI-100	0 . 0 . 0 . 0	0
	821EF V3	0 . 0 . 0 . 0	0
	401E	0 . 0 . 0 . 0	0

LAN BASE: AR-7xx/8xxE

Node Range: 000 - 007

Yes Exit


Click on button 3, Line



Click on the box marked +



The Keypad will now be online, indicated by a white Y in a blue disc



The Keypad is now online and ready to program.

NOTICE

Refer to the 701 Client and 701 Server manuals for programming information. Refer to Additional Connection Diagram on page 19 for details on connecting AR-485REP RS485 repeaters if connecting more than 32 Networked Keypads.

NETWORKING

Networking Under an AR-716E

1. Setting Node ID

To Set Node ID → 00 * Node ID of Keypad #

Example

1. Setting Node ID

To Set Node ID →

Enter Programming Mode → * MASTER CODE # → 00 * 001 # → * #

NOTICE

*Refer to the AR-716E manual and 701 Client and 701 Server manuals for further programming information.
Refer to Additional Connection Diagram on page 19 for details on connecting AR-485REP RS485 repeaters if connecting more than 32 Networked Keypads.*

PROGRAMMING TABLE

Command List		
Function	Command	Control Mode
Entering Programming Mode	* 123456 # or * Master Code # (If Already Changed)	M4/6/8
Exiting Programming Mode	* #	M4/6/8
Exiting Programming Mode and Enabling Arming Status	* * #	M4/6/8
Node ID Setting Connected to 716E For More Than 254 Units	00 * NNN # (NNN = Node ID: 001 – 254)	M4/8
Node ID Setting Connected To PC For Up to 254 Units	00 * NNN * VVV * nnn # (NNN = Node ID of K50i, VVV = Virtual 716E Node ID, nnn = Door Number)	M4/8
Lock Relay Time Setting	02 * TTT # (TTT = Lock Relay Time, 000 = Toggle, 001 – 600 = 1 – 600 Sec, 601 – 609 = 0.1 – 0.9 Sec)	M4/6/8
Arming Relay Time Setting	03 * TTT # (TTT = Door Relay Time, 000 = Toggle, 001 – 600 = 1 – 600 Sec)	M4/6/8
Control Mode Setting	04 * N # (N = Mode 4/6/8)	M4/6/8
Arming Delay Time Setting	05 * TTT # (TTT = Arming Delay Time, 001 – 600 = 1 – 600 Sec)	M4/6/8
Alarm Delay Time Setting	06 * TTT # (TTT = Arming Delay Time, 001 – 600 = 1 – 600 Sec)	M4/6/8
Auto-Open Zone Setting	08 * N * HHMMHHMM * 111111 # (N = 2 Sets of Auto Open Zone, HHMMHHMM = Start Time to End Time, 111111 = Days S/M/T/W/T/F/S - 0 = Disable, 1 = Enable)	M4/6/8
Master Code Setting	09 * PPPPPRRRRRR # (PPPPPP = Master code, RRRRRR = Repeat Master Code)	M4/6/8
Deleting Tokens/User Codes	10 * SSSSS * EEEEE # (SSSSS = Start Address, EEEEE = End Address)	M4/6/8
Setting PWD/PIN	12 * UUUUU * PPPP # (UUUUU = User Address, PPPP = 4 – Digit User Code)	M4/6/8
Arming Output Time Setting	14 * TTT # (TTT = Arming Output Time, 001 – 250 = 1 – 250 Sec)	M4/6/8
Duress Code Setting (M4/M8)	15 * PPPP # (PPPP = 4 Digit Duress Code)	M4/8
Common Code Setting (M6)	15 * PPPP # (PPPP = 4 – Digit Common Code - Set to 0000 to disable)	M6
Door Close Time	18 * TTT # (TTT = Door Close Time, 001 – 600 = 1 – 600 Sec, Default = 15 Sec)	M4/6/8
Adding Tokens	19 * UUUUU * QQQQQ # (UUUUU = User Address, QQQQQ = Token Quantity)	M4/6/8
Factory Setting 1	20 * DDD # (DDD – Refer to Chart A 20*DDD# on Page 29 for Details)	M4/6/8
Lift Control Setting: Multi Doors	21 * UUUUU * S * FFFFFFFF # (UUUUU = User Address, S & F - Refer to Charts on Page 25 for Details)	M4/6/8
Relay Time Of Lift Controller Setting	23 * NNN * TTT # (NNN = Node ID, TTT = Relay Time, 001 – 600 = 1 – 600 Sec)	M4/6/8
Factory Setting 2	24 * DDD # (DDD – Refer to Chart B 24*DDD# on Page 29 for Details)	M4/6/8
Real Time Clock Setting (Stand-Alone)	25 * YYMMDDHHmmss # (YYMMDDHHmmss = Year/Month/Day/Hour/Minute/Second)	M4/6/8
Anti-Passback (Enable User)	26 * SSSSS * EEEEE # (SSSSS = Start Address, EEEEE = End Address)	M4/6/8
Lift Control Setting (Single Door)	27 * UUUUU * FF # (UUUUU = User Address, FF = Floor Number 01 – 32)	M4/6/8
Force Open Alarm Setting	28 * NNN # (NNN – Refer to Chart C 28*NNN# on Page 29 For Details)	M4/6/8
Delete All Users	29 * 29 * # followed by * #	M4/6/8

TABLE OF USERS

Name of On-Site Programmer(s):

Installation Company:

DEFAULT MASTER CODE:- * 123456 #

Tel:

Date:

USER MASTER CODE:

Lock Time:

Lock Type:

[illegible]

We recommend this page should be filled in and regularly updated and kept in a safe and secure location by the person responsible for the upkeep of the system.